



EVACUATION DIAGRAM

Customer Name

Customer Address

Assembly Area 1 – Grass Vere of Drive way

Assembly Area 2 – Grass Verge of Drive way

IN CASE OF FIRE

R REMOVE PEOPLE
FROM IMMEDIATE DANGER

A ALERT FIRE SERVICE
CALL 000
BREAK MANUAL CALL POINT
ADVISE FIRE WARDEN OF LOCATION

C CONFINE FIRE AND SMOKE
CLOSE DOORS AND WINDOWS
(IF SAFE TO DO SO)

E EVACUATE
TO THE ASSEMBLY AREA

EVACUATION PROCEDURE

STAGE 1: Removal of people from Immediate Danger Area

Occupants and staff in the immediate danger area are to assemble a safe distance away from the fire and smoke. When the area has been evacuated all doors and windows should be closed to contain fire.

STAGE 2: Removal To Safe Area

If the severity of the smoke or fire warrants further evacuation, occupants should be moved through fire/smoke doors to a safe area.

STAGE 3. Complete Evacuation of Entire Complex
Should the emergency necessitate evacuation of the whole building, the Warden or the Fire Service will direct occupants from the safe place to the ASSEMBLY AREA. (Do not Re-enter the Building until Clearance is Given by Authority.)

STAGE 4. ROLL CALL

To be conducted as soon as possible and ensure all Persons are accounted for. Report all missing persons to **FIRE OFFICERS**.





Mobility Impaired persons should evacuate immediately on hearing the fire alarm assisted by a nominated person.



FCF - FIRE AND ELECTRICAL
1300 323 753
www.fcfnational.com.au
fireevacdiagrams.fcfnational.com.au

DATE OF INSTALLATION: JULY 2026
VALID TO: JULY 2031
REVIEW DATE: JULY 2027

SITE MAP



NOT TO SCALE

LEGEND

DIAGRAM COMPLIES WITH THE MINIMUM ELEMENTS OF SECTION 3.5.5 OF AS3745:2010



PRIMARY ROUTE



SECONDARY ROUTE



DESIGNATED EXIT



ASSEMBLY AREA



ABC FIRE EXTINGUISHER



CO2 FIRE EXTINGUISHER



FIRE HYDRANT



FIRE HOSE REEL



FIRE BLANKET



MANUAL CALL POINT



WIP